


Datasheet

Subject to technical alteration
Issue date: 05.08.2020 • A111



» APPLICATION

The fancoil controller with radio receiver in high-quality design is used for individual temperature control and control of fancoil units in hotels, offices and living rooms. Two configurable inputs can be used as sensor input, room occupancy or energy lock. In addition to wired valve actuators r, sensors and actuators can also be controlled by radio. In addition, as an alternative to wired sensors, an external radio temperature sensor, radio motion detector, a radio temperature sensor for changeover function and radio window contacts/handles can be learnt in. The override by radio is possible by means of higher-level controller profile and cable-bound via Modbus. Radio and wired sensors and actuators are processed identically and can be used in any combination. This guarantees individual and energy-efficient room air conditioning. The device (front of glass in white or black) has a monochrome display and touch-sensitive control buttons. It has a timer with three time channels of four time periods each. Mounting is designed for a flush-mounted box. For hotel applications, the device offers the option of an additional zone (bathroom heating) in conjunction with room temperature sensor and radio actuator SAB.

JOY SR Fancoil EC AO2DO (85..260 V ~)

Modern fan coil room thermostat to control fan coil units with EC fans. It is suitable for 2- and 4-pipe systems. It has 2 relays and 1 analogue output 0-10V (heating valve, cooling valve and EC fan). The device combines a modern design with a 2,5" LCD and a touch-sensitive surface, 3 time program options each with 4 time periods options.

JOY SR Fancoil EC 3AO (24 V ~/=)

Modern design, flush mounting fan coil room thermostat. Used for individual control of temperature in commercial, industrial and residential buildings. It is tailored for two-pipe and four-pipe fan coil units with two-wire electric valves or controlling a 6-way valve. The device combines a modern design with a 2,5" LCD and a touch-sensitive surface, 3 time program options each with 4 time periods options.

» SECURITY ADVICE – CAUTION



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

» NOTES ON DISPOSAL



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

» REMARKS TO ROOM SENSORS

Location and Accuracy of Room Sensors

The room sensor should be mounted in a suitable location for measuring accurate room temperature. The accuracy of the temperature measurement also depends directly on the temperature dynamics of the wall. It is important, that the back plate is completely flush to the wall so that the circulation of air occurs through the vents in the cover. Otherwise, deviations in temperature measurement will occur due to uncontrolled air circulation. Also the temperature sensor should not be covered by furniture or similar devices. Mounting next to doors (due to draught) or windows (due to colder outside wall) should be avoided. The temperature dynamics of the wall will influence the temperature measurement. Various wall types (brick, concrete, dividing and hollow brickwork) all have different behaviours with regards to thermal variations.

Surface and Flush Mounting

The temperature dynamics of the wall influence the measurement result of the sensor. Various wall types (brick, concrete, dividing and hollow brickwork) have different behaviours with regard to thermal variations. A solid concrete wall responds to thermal fluctuations within a room in a much slower way than a light-weight structure wall. Room temperature sensors installed in flush boxes have a longer response time to thermal variations. In extreme cases they detect the radiant heat of the wall even if the air temperature in the room is lower for example. The quicker the dynamics of the wall (temperature acceptance of the wall) or the longer the selected inquiry interval of the temperature sensor is the smaller the deviations limited in time are.

» PRODUCT TESTING AND CERTIFICATION



Declaration of conformity

The declaration of conformity of the products can be found on our website <https://www.thermokon.de/>.

» DIAGNOSTICS MENU

To access the diagnostics menu, select the header in the startscreen of the parameter menu, and press the ENTER key. Here you will find various information, such as device type, software version, state of the inputs and outputs and controller state (current manipulated variable).

» MOUNTING ADVICES

Plasterboard boxes shall be covered by wall paper or paint to avoid that the plasterboard box's front rim will be partially visible underneath JOY. Maybe consider using white plasterboard boxes (i.e. Kaiser 9063-77)

» **TECHNICAL DATA**

Measuring values	temperature	
Network technology	RS485 Modbus	
Measuring range temp.	0..+50 °C	
Accuracy temperature	±1 K (typ. at 21 °C)	
Control function	setpoint adjustment 0..+50 °C, fan stages	
Display	LCD 2,5", 240x160 px, white backlighting	
Functions	integrated PI-controller, MSG server for 2nd control loop via radio	
Enclosure	PC and glass, optional black or white	
Protection	IP30 according to EN 60529	
Connection electrical	Terminal 1..8 terminal block max. 1,5 mm ²	Terminal 9..12 terminal block max. 1.0 mm ²
Ambient condition	0..+50 °C, max. 85% rH non-condensing	
Weight	195 g	
Mounting	flush mounted with standard EU box (Ø=60 mm)	
Notes	there are 20 EnOcean transmit / receive channels available for various functions	

JOY FANCOIL EC AO2DO

Output voltage	1x 0..10 V, max. load 5 mA, EC FAN control	
Output switch contact	2x normally open contacts (heating/cooling), 240 V max. load 500 mA	
Power supply	85..260 V ~	
Power consumption	max. 3 VA (260 V ~)	
Inputs	DI1 input for NTC 10 K or floating contact	DI2 digital input for non-floating contact

JOY FANCOIL 3AO

Ausgang Spannung	3x 0..10 V, max. Last 5 mA, Ansteuerung EC Lüfter, Heizen & Kühlen oder Ansteuerung 6-Wege-Ventil (konfigurierbar via Software)	
Spannungsversorgung	24 V = (±10%) oder 24 V ~ (±10%) SELV	
Leistungsaufnahme	max. 2,5 W (24 V =)	
Eingänge	DI 1 1 Eingang für NTC10k oder potentialfreien Kontakt	DI 2 Eingang digital, für potentialfreien Kontakt

***Power supply**

When several BUS devices are supplied by one 24 V AC voltage supply, it is to be ensured that all "positive" operating voltage input terminals (+) of the field devices are connected with each other and all "negative" operating voltage input terminals (-) (=reference potential) are connected together (in-phase connection of field devices).

In case of reversed polarity at one field device, a supply voltage short-circuit would be caused by that device. The consequential short-circuit current flowing through this field may cause damage to it.

Therefore, pay attention to correct wiring.

» INFORMATION ABOUT EASYSSENS® (RADIO) / AIRCONFIG GENERAL USAGE



EasySens® - airConfig

Basic information about EasySens® radio and about general usage of our airConfig software, please download from our website.

» OVERVIEW OF THE RADIO TELEGRAMS



EEP

The structure of the data contained in the telegram can be found in the EEP (EnOcean equipment profile) list provided by the EnOcean Alliance.

» SUPPORTED PROFILES


Receiving profiles

EnOcean-EEP	Type	Direction	Description	Thermokon Devices	Max. Quantity	LCD/ Funktions- gruppe
F6-02-01	RPS	Rx	EnOcean button	Diverse	1	RPS
D5-00-01	1BS	Rx	Windows contacts	SRW01	max.5	SRW
F6-10-00	RPS	Rx	Windows handle	SRG02		SRG
A5-02-06	4BS	Rx	Temperature 0-50°C	SR65 VFG, SR65 TF, SR65 AKF, SR65	1	VFG
A5-02-16	4BS	Rx	Temperature 0-80°C			VFG
A5-02-05	4BS	Rx	Room Sensor (Temperature 0-40°C)	SR04, LC-SR04, SR07, SR65	1	EXT
A5-10-03	4BS	Rx	(Room Operating Panel) Temperatur, Set Point	SR07P, SR04P, SR06 2T/2T+		WRF
A5-07-01	4BS	Rx	Room Sensor (Occupancy)	SR-MDS Solar, SR- MOC Solar, SR-MOW Solar	max. 3	OCC
A5-08-01	4BS	Rx	Room Sensor (Occupancy, Light, Temperature)	SR-MDS		OCC
F6-04-01	RPS	Rx	Keycard	SR-KCS02, SR-KCS	1	KEY
A5-20-01	4BS	Rx/Tx	SAB	SAB+, SAB05	max. 6	SAB
A5-20-12	4BS	Rx	Superior Control Unit (Fan, Set Point, Controller, Energy Hold OFF/Dew point, Occup)		1	SUP

Transmitting profiles

EnOcean-EEP	Type	Direction	Description	Max. Quantity	LCD
A5-10-02 (V2.1.1 +)	4BS	Tx	<i>Valid from Version 2.1.1 (up to 2.1.0: A5-10-01)</i> Room operating panel (Fan, Temp, Sollwert, Occup)	1	WRF
A5-10-06 (V2.1.1 +)	4BS	Tx	<i>Valid from Version 2.1.1 (up to 2.1.0: A5-10-05)</i> Room operating panel (Temp, Sollwert, Occup)		
A5-11-02	4BS	Tx	Temperature Controller (Fan, Set point, alarming, Controller state, Energy Hold OFF, Occup)	1	OUT
A5-20-01	4BS	Rx/Tx	SAB	max. 5+1	SAB

» CONNECTION PLAN



1 EC Fan GND	1 Digital Input 2
2 EC Fan (0..10 V)	2 EC Fan (0..10 V)
4 Cooling	3 Cooling (0..10 V) or 6-way valve
5 Heating	4 Heating (0..10 V) or 6-way valve
6 Digital Input 2 (230V)	5 GND DI 2
7 L	6 GND
8 N	7 24 V = (±10%) or 24 V ~ (±10%)
12 Modbus B	8 GND
11 Modbus A	12 Modbus B
10 GND DI 1	11 Modbus A
9 Digital Input 1 (or NTC10K)	10 GND DI 1
	9 Digital Input 1 (or NTC10K)

Note: Parallel connection of the potential-loaded inputs is not permitted!

If the operating mode (change-over DI) of several devices is to be switched together by one contact, the potential-free 230V input must be used (DI2, only possible with the 230V version). It must be ensured that the same phase is used for jointly switched devices.

» CONFIGURATION VIA MODBUS OR SD CARD



Configuration software:
uConfig

The JOY room thermostat can be parameterised using the uConfig configuration software.

The online installer for the configuration software can be found in our download center. The installer retrieves all necessary files and plug-ins from our web server.

A separate offline installer is available for installations on PCs without Internet connection.

→ [Download Online-Installer](#)

» FUNCTION DESCRIPTION – CONTROLLER/FAN STAGES

JOY FANCOIL EC AO2DO (85..260 V ~)	JOY FANCOIL EC 3AO (24 V ~/=)
PI controller (PWM) & 2-point/3-point controller (configurable)	PI controller (0..10 V)

Fan stages (all types)

In automatic mode the fan speed is linked to the controller. The assignment of the fan stage to the control (heating / cooling, only heating, only cooling) is freely selectable. To ensure that the fan motor starts reliably, a period of time can be configured in which the fan starts with maximal value. Using one or more time channels, the fan control have to be set per timechannel and per period. Via the touch surface the user has the option to override the settings of the device every time. When the next time channel starts, the fan speed is set to the configured value. The fan is set to automatic mode when the user changes the occupancy state (occupied↔unoccupied).

Heating/ cooling with PI-controller (PWM) (only EC AO2DO)

The time response of the PI control loop depends on the control parameters x_p for the proportional area and t_n for the reset time of the integral range. In case of an error, the P portion immediately changes the position value proportionally to the error variable, while the integral portion takes effect after a certain time.

The resulting actuating variable is output as a pulse-width-modulated signal directly to the outputs.

Heating/ cooling with 2-point-/ 3-point-controller (only EC AO2DO)

In the case of temperature control, the 2-point controller only knows the switching states heating ON and heating OFF. The 3-point controller also knows the switching state of cooling. Two - and three-point controller work with a hysteresis.

Heating/ cooling with PI-controller (0..10 V) (only EC 3AO)

The time response of the PI control loop depends on the control parameters x_p for the proportional area and t_n for the reset time of the integral range. In case of an error variable, the P portion immediately changes the position value proportionally to the error variable, while the integral portion takes effect after a certain time.

The resulting manipulated variable is output as an analogue 0..10 V signal directly to the outputs.

EC Fan automatic mode (only EC 3AO)

The 0..10 V (0..100%) control of the fan is proportional to the calculated manipulated variable of the PI controller.

Example:

Calculated actuating variable 65% → Fan control with 6,5 V.

Calculated actuating variable 22% → Fan control with 2,2 V.

EC Fan manual (only EC 3AO)

Up to 5 steps (steps) can be set using the configuration software. The set number of steps is divided linearly to the manipulated variable of 0..100%.

Example:

Max. steps (stages) = 5

Stage 1 = 20%

Stage 2 = 40%

Stage 3 = 60%

Stage 4 = 80%

Stage 5 = 100%

Max. steps (stages) = 3


Stage 1 = 33%

Stage 2 = 66%

Stage 3 = 100%

» **FUNCTION DESCRIPTION - BUTTONS**


On the touch surface, there are adjustment options for setpoint and fan speed regulation.



The Power button (E) can be used to switch the room thermostat to standby mode (not possible if the Keycard switch function is used!) If the key is used as a presence key at the same time, the key must be pressed for at least 3s, in all other cases a short press is sufficient. In standby mode the display and all outputs are switched off (controller deactivated). The frost and heat protection monitoring remains active. **Modbus registers can still be read (e.g. room temperature).**

Main screen/ Value display

The Display shows the measured value of the internal sensor. The value of an external sensor will be shown if connected and configured accordingly. The room thermostat controls in this case according to the external sensor.



Header

In the header line, the time, weekday and date are displayed. In addition, the ECO info symbol (sheet) is displayed here when the ECO mode is switched on. It is possible to show an alarm symbol (exclamation mark) in the display. This symbol is located at the same position as the ECO symbol. Since the alarm symbol has a higher priority, it overwrites the ECO symbol.

Footer

Depending upon the heating or cooling mode, occupancy or window contact status, the corresponding symbols will be shown in the footer. The symbol “active timechannel” will be shown only if active.

Symbols


Occupancy



Window contact/dewpoint



Heating/Cooling



Fan Speed




Active timechannel



» CONFIGURATION

Buttons



The configuration menu is activated by simultaneously pressing the buttons "up" (A), "left" (D) and "right" (B) for at least 3 seconds. Menu navigation on the touch-surface is performed by pressing the buttons "up" (A), "down" (C), "left" (D), "right" (B) or the power button. Choose the desired parameter and press "right" (B) to open up the submenu. If no entry is made for 8 minutes, the parameter menu is left automatically. To exit the menu select the header line and press "left" (D).

Menu	
Timechannel	▷
Time/Date	▷
Sensor settings	▷
Common settings	▷
EnOcean list	▷
EnOcean configuration	▷

» MENU → TIME CHANNELS

In the Time Channels menu, setpoint and timer can be set. Up to 3 time channels with 4 time periods each can be parameterized. The time channels are prioritised. Channel 3 has the highest priority. After selecting the line of the time channel to be edited, the next submenu is called up with the "Right" key. It is possible to set any time period within one week in the first two lines with the "Left" (-) / "Right" (+) keys. In addition, the ECO mode is available in the menu sections. In ECO mode, the dead zone between heating and cooling is automatically set to the ECO dead zone configured in the "General Settings" menu (default: 10 K).

Timechannels			
Timechannel 1	Mo - Fr	▷	
Timechannel 2		▷	
Timechannel 3		▷	

Timechannels/Timer1	
from day	<-/+> Mo
to day	<-/+> Fr
1: 06:00h - A - 22.0°	✓▷
2: 08:30h - 1 - 20.0°	✓▷
3: 16:00h - A - 22.0°	✓▷
4: 22:30h - 0 - 22.0°ECO	✓▷

Periods/Period1	
Start	<-/+> 06:00h
Fan	<-/+> AUTO
Temp	<-/+> 22.0°
ECO-Mode	✓

» MENU → TIME/DATE

Time, Date and display format can be configured in the menu settings. The room thermostat is equipped with a real-time clock so that it automatically adjusts for daylight-saving time. This function can be disabled in the datetime settings.

Menu		
Timechannels	▷	
Time/Date	▷	
Sensor settings	▷	
Common settings	▷	
EnOcean list	▷	
EnOcean configuration	▷	

Datetime setting/Time	
Hour	<-/+> 13
Minute	<-/+> 07
12h/24h	<-/+> 24h
Daylight saving	<-/+> CET
Date	▷

Datetime setting/Date	
Day	<-/+> 12
Month	<-/+> 08
Year	<-/+> 15
Presentation	<-/+> T.M.J

» **MENU → SENSOR SETTINGS**

Offset correction for internal and external sensor value. The temperature display can also be changed from °C to °F.

Sensor settings		
Offset int.	◀-/▶	0.6 K
Value int.		22.1°C
Offset ext.	◀-/▶	0.2 K
Value ext.		22.1°C
Unit	◀-/▶	Celsius

» **MENU → COMMON SETTINGS**

The common settings includes the brightness of the background lighting and the LED. Valve protection prevents the valves becoming ceased when they are switched off for long periods. If the valve protection function is activated, a valve-check is carried out every Friday at 11:00 am for the heating valve and 11:15 am for the cooling valve. The corresponding valve is triggered for 5 minutes, if not activated during the last 96 hours. The dead band can be adjusted (default 10.0 K, see timechannels). The room thermostat has 3 outputs for fan control with up to 3 fan stages. The amount of fan stages are configurable.

Menu	Settings/Common	Settings/Common	Settings/Language
Timechannels	Brightness LCD ◀-/▶ 100%	Valve protect ◀-/▶ ON	Deutsch ✓
Time/Date	Brightness LED ◀-/▶ 100%	ECO deadband ◀-/▶ 10.0K	English
Sensor settings		Fanstages ◀-/▶ 3	
Common settings		heat load max ◀-/▶ 2A	
EnOcean list		cool load max ◀-/▶ 2A	
EnOcean configuration	Common ▶	Language ▶	Factory setting ▶

Heat / Cool load

The maximum heating and cooling load can be set by the user for the best compensation of the sensor self-heating. This method ensures the accuracy of the internal temperature measurement.


Factory settings

By selecting "Factory setting", the room thermostat will be reset and restore the device to factory default settings.

» **PARAMETER MENU – MODBUS INTERFACE**

The configuration menu is activated by simultaneously pressing the buttons "up" (A) and "down" (C) for at least 5 seconds.

The menu is enabled during the first 60 minutes after switching on the supply voltage as long as the device is not actively involved in Modbus communication. As soon as the device receives a valid request addressed to the device from a DDC, access to the menu is blocked. Without valid communication, access is blocked after 60 minutes!



Modbus settings		
Address	◀-/▶	32
Baudrate	◀-/▶	19200
Parity	◀-/▶	Even

Address (default: 32)
Adjustable address (1-247)

Baud rate (default: 19200)
9600Bd | 19200Bd | 38400Bd | 57600Bd


Parity (default: even)
Non | odd | even

» ENOCEAN

There are 20 channels available that can be assigned different functions. A channel can be configured as a receive channel, as a send channel or as a message server (SAB communication).

6 channels can be configured with SAB valve actuator, one of these can be set with the bath function. For the SAB with the bath function, an additional setpoint offset can be set. If SAB valve actuators are learned in, the analogue outputs to the internal controller remain active and can also be used.

Functional Overview SAB



The profiles used are divided into functional groups:

SRW/SRG	Window contact and window handle. Both have an influence on the window contact function and are linked to the digital inputs or the Modbus default. Up to five sensors can be learned-in.
VFG	Sensor for chngeover control. Only one changeover sensor can be learned in.
EXT/WRF	Receiving channel: Temperature preset by an external room temperature sensor. Overrides the internal temperature sensor. Max. one sensor can be learned in. An EnOcean room operating unit is displayed on the send channel.
OCC	Up to 3 motion sensors can be learned in and affect the occupancy function. The last changed value (Modbus,EnOcean, Button) will be accepted. If several EnOcean motion sensors have been learned-in, the "ROOM UNOCCUPIED" value will only be accepted once all sensors have signaled "ROOM UNOCCUPIED".
KEY	Controls the internal keycard function. When learning a key card switch, the card must not be plugged in AND pulled immediately during the learn-in process. It is necessary to wait at least 5 seconds until the second action is performed with the card. Only then will the switch be assigned as key card switch, otherwise it will be learned in as a radio rocker switch (function group RPS).
SUP	A superior control unit to override the internal functions.
SAB (5+1 Bath)	Up to 6 SAB's can be learned in. One pcs. can be assigned with the „Bath“ function. The other channels can be used optionally for heating or cooling. For each SAB channel, an offset for the setpoint can be configured via Modbus.
OUT	Only in direction of transmission. A controller status (A5-11-02) every 15 minutes (configurable) and with every change of any value.

Commissioning

Two additional selection menus appear in the menu, <EnOcean list> and <EnOcean configuration>. The EnOcean list is a simple list display of the EnOcean sensors that have been taught in, in addition to the list, further information on the individual sensors can be called up.

EnOcean list

All channels with the learned sensors or actuators are displayed in this list.

With <Selection>, detailed information are displayed:

1 Rx 01-8C-03-98 EXT !!	Index: 2 ID: FF-81-CC-01 Dir: Rx Typ: SAB EEP: A5-20-01_B SAB-Ch: 2 RSSI: -67dB Time: 340s Errors: 00001 Pending: Y Sensor Channel: 2
2 Rx FF-81-CC-01 OCC	
3 FF-FF-FF-FF	
4 Rx FF-81-CC-03 SAB	
5 Rx FF-81-CC-00 VFG !!!	
6 Rx 00-8B-CE-DA KEY	
< Selection >	ENTER to acknowledge

EnOcean configuration

In this menu item, the radio channels can be configured and individual information can be called up.

In the footer, various menu items can be selected with the LEFT / RIGHT keys and the corresponding menu item is selected with the ENTER key.

SAB valve actuators are learned in with the function <SET ACTOR>.

1 FF-FF-FF-FF	EXIT DELETE CHANNEL < LEARN SENSOR > SET ACTOR SHOW CHANNEL
2 FF-FF-FF-FF	
3 FF-FF-FF-FF	
4 FF-FF-FF-FF	
5 FF-FF-FF-FF	
6 FF-FF-FF-FF	

The access to the menu <EnOcean configuration> can be protected with a password via Modbus. The login remains unlocked in the EnOcean menu until 10 minutes after the last key press. Default password: 2030.

More detailed information for the configuration of the EnOcean channels can be found in the specification.

» INPUTS

Up to 2 inputs are configurable for functions such as windows contact, dew point, occupancy, change-over or external sensor option.

The overview of possible combinations can be found in the software specification of the JOY.

Sensor (NTC10K)

The value of an external sensor will be shown if connected and configured accordingly. In this case, the room thermostat controls according to the external sensor.

Change-Over DI

Which controller is active depends on the state of the Change-Over contact. (Factory default: contact open heating controller active, contact closed cooling controller active). The terminals 4 and 5 are used as outputs for heating resp. cooling.

Change-Over Sensor

The Change-Over Sensor is used for switching between heating and cooling mode automatically. If the temperature is below 22 ° C, the controller is in cooling mode. If it is above 25 ° C, it is a heating mode.

If an input is configured as a change-over, the room thermostat is automatically in 2-pipe operating mode and both outputs (terminals 4 and 5) are used as outputs for heating resp. cooling.

Window contact/Energy hold off

If a window contact is enabled via the digital input, the reference will switch to a setback set point (Heat SP/Cool SP).

Dewpoint

An active dewpoint contact locks the cooling controller.

Occupancy

If occupancy-function is active, the symbol will be displayed automatically. In state of "unoccupied" the heating set point is reduced by 2K (default setting) resp. the cooling set point raised by 2K.

Keycard-Switch

When the card is not inserted, the device is switched in sleep mode. Operation of the keys is locked, the display is switched off and the controller adjusts to the nominal values of the "unoccupied"-State.

Alarm contact

An alarm symbol can be shown in the header of the display. The backlight flashes when the alarm is active. This symbol is in the same position as the ECO symbol. The alarm symbol has a higher priority and overwrites the ECO symbol!

» APPLICATION NOTICE

Boot Loader

A bootloader integrated in the device, makes it possible to install a new application (update, upgrade) using a MicroSD card. To insert the SD card, the upper part must be removed. If the boot loader is activated, the ring illumination blinks in a 1s cycle, while display is not triggered! After recognition of a MicroSD card with a valid application the update process is started. Now, ring illumination blinks fast in a 300ms cycle. After a successful update process (Duration approx. 20-30 seconds!), the new application is started automatically. Afterwards, SD card have to be removed! A firmware update can also performed via the Modbus interface. In this case, the program "Thermokon Bootloader" (as of version 2.0.0) and the corresponding firmware file are needed.

SD-Card

The parameterization of the receive channels for EasySens transmitter (i.e. SRW0x window contact) and the configuration of the device can be done with a MicroSD card. You can create a configuration file with the Thermokon tool uConfig. This means that sensors can be learned-in without having to press the LRN buttons of the relevant sensors.


The MicroSD card can also be used to read a configuration from the JOY. The MicroSD card can be plugged in during the current configuration or it can be used after the configuration has been completed. If a MicroSD card is inserted during the configuration, each learn / learn process is wrote directly into the file. If the MicroSD card is inserted after the configuration, the configuration file is automatically created on the card after a restart.

Note: EasySens receivers such as SAB or actuators need the ID of the transmitter (Joy) via manually initiated teach-in telegram. Only MicroSD cards formatted in the FAT file system can be used! NTFS and exFAT file systems are not supported.

Software manual

A detailed description of the parameter and the configuration software uConfig can be downloaded from our website.

» DIMENSIONS (MM)



» ACCESSORIES (OPTIONAL)

Converter RS485 Modbus - USB
Decorative frame pure white for JOY
MicroSD card 2GB

Item No. 668293
Item No. 614771
Item No. 500098