



#### Model

RCJ01E5001-01 1-channel 868.30 MHz

#### **Technical Data**

Frequency: 868.30 MHz Modulation: FSK

230 V AC / 50 Hz Power supply: Current consumption: approx. 35 mA 1 potential-loaded relay Output: contact (N.O.)

Max. contact rating: see Table of loads Operating temperature: -20°C to +60°C

#### Table of Loads

| Type of Load       | max. load       |
|--------------------|-----------------|
| Resistive Load:    |                 |
| Light bulbs, 230 V |                 |
| Halogen lamps etc. | 10 A / 2,300 VA |
| Inductive Load:    |                 |

Halogen lamps with wound

transformers 2.6 A / 600 VA (transformator at least 85% loaded)

Non-compensated or series-

compensated fluorescent lamps

with ferromagnetic ballasts 10 A / 2,300 VA

Parallel-compensated fluorescent lamps with

2.6 A / 600 VA ferromagnetic ballasts

Capacity EB: electronic

ballasts, electronic

4 A / 920 VA transformers etc.

### Safety Advice



Carefully read through these instructions before connecting and operating the unit!

#### Caution! Electrical installation may only be carried out by a qualified electrician!

Observe the applicable laws, standards and regulations as well as the manufacturer's instructions for the devices to be operated!

Have faulty units checked by the manufacturer! Do not make any unauthorized alterations or modifications to the unit!

The relay contact is only suitable for a singlephase power supply!

Warning! Take care not to damage the antenna insulation!

The antenna could be live!

# Intended Use

This unit may only be used as an Easywave radio control together with mains-powered devices!

The manufacturer shall not be liable for any damage caused by improper or non-intended use!

#### **Function**

The Junction Box Receiver is designed for switching mains-powered devices in the operating modes ON/OFF and Timer.

The receiver can be operated by multi-channel transmitters or single-channel transmitters.

## **Using the Junction Box Receiver**

- 1. Mount the receiver in accordance with the onsite conditions.
  - Note: The receiver fits into almost every junc-
- Connect the power supply and the devices to be switched according to the connection diagram. Caution! Observe the applicable electrical regu-
  - After connecting the receiver is in operating mode. The LED is off.
- Transfer the codes of the transmitters to the receiver (see section "Memorizing the Transmitter Codes")

Mounting Advice: avoid mounting at the following locations, because this will affect the range:

- in a distribution box or housing made from metal
- in the immediate vicinity of large metal objects
- on the ground (or near it).

## **Programming and Operating Modes**

For programming (see "Memorizing the Transmission Codes (Programming)" there are 3 programming modes for the 3 operating modes of the re-

These programming modes are displayed by different LED flashing patterns.

| Prog<br>Mode | Operating Mode                                       | LED Flashing<br>Pattern |
|--------------|--|-------------------------|
| 1            | ON/OFF<br>(2-button operation)                       | www                     |
| 2            | ON/OFF<br>(1-button operation)<br>>1,6 s: OFF        |                         |
| 3            | Timer mode 7 minutes, retrigger (1-button operation) |                         |

You can change from the operating mode to the programming mode 1 and from one programming mode to the next by briefly (< 1.6 sec.) pressing the programming button: Operating Mode -> Programming Mode 1 -> Programming Mode 2 -> Programming Mode 3 -> Operating Mode etc.

## **Memorizing the Transmission Codes** (Programming)

In the "Memorizing the Transmission Codes" mode you can transfer the codes of your transmitters to the receiver.

Note: Generally you only have to transfer the code of one button per transmitter channel. The code of the other transmitter buttons will be assigned automatically.

- Briefly (< 1.6 sec.) press the programming button.
  - Programming mode 1 is activated. The LED flashes. If necessary change the programming mode (see "Programming and Operating
- 2. Press and hold a transmitter channel button. As soon as the code has been memorized, the LED lights up for 4 sec. and then flashes again. Release the transmitter button.
- Repeat step 2 with the other transmitters. You can memorize up to 32 transmitter codes into
- Briefly (< 1.6 sec.) press the programming button to return to the operating mode.

Note: In case of a longer power failure programming of the receiver remains.

### **Deleting Specific Transmission Codes**

In the delete mode you can delete specific transmission codes memorized by the receiver.

- 1. Keep the programming button pressed for more than 1.6 sec. The delete mode is activated. The LED flashes rapidly.
- Press the selected transmitter channel button. As soon as the code has been deleted, the LED lights up for 4 sec. and then flashes again rapid-
- Repeat step 2 with another transmitter or briefly (< 1.6 sec.) press the programming button in order to return to the operating mode.

## **Reset (Deleting Memory Completely)**

In the reset mode you can delete all codes memorized by the receiver.

- Keep the programming button pressed for more than 1.6 sec. The delete mode is activated. The LED flashes rapidly.
- Press the programming button again and keep it pressed for more than 1.6 sec. If the memory has been deleted completely, the LED lights up for 4 sec. and then flashes again rapidly.
- Briefly (< 1.6 sec.) press the programming button to return to the operating mode.

#### **General Information**

#### Disposal

Waste electrical products should not be disposed of with household waste!

Dispose of the waste product via a collection point for electronic scrap or via your specialist dealer



Put the packaging material into the recycling bins for cardboard, paper and plastics.



# Warranty

Within the statutory warranty period we undertake to rectify free of charge by repair or replacement any product defects arising from material or production

Any unauthorized tampering with, or modifications to, the product shall render this warranty null and

# Conformity

Hereby, ELDAT GmbH declares that the radio equipment type RCJ01 is in compliance with RED Directive 2014/53/EU.



The full text of the EU declaration of conformity is available at the following internet address: www.eldat.de

## **Customer Service**

If, despite correct handling, faults or mal-functions occur or if the product was damaged, please contact your retailer or the manufacturer.

## **ELDAT GmbH**

Im Gewerbepark 14 15711 Königs Wusterhausen Germany Phone: + 49 (0) 33 75 / 90 37-310 Fax: +49 (0) 33 75 / 90 37-90 Internet: www.eldat.de e-Mail: info@eldat.de